





Wireless Security Camera



1080P Full HD



Weather Resistant



Two-Way **Audio**



Motion **Detection Notification**



2.4G Wifi



PIR Motion Dectetion



Night Vision



110° Wide-angle Camera Lens



Long **Battery Life**



Sound and Light Expulsion Alarm





Product Features

- Equipped with sound and light expulsion alarm.
- Built in battery; supports sustainable standby for 8 months normal use for 6 months
- Outdoor and waterproof
- Secure 1-minute setup.
- Built in IR still visible at night.
- 110-degree field of view with 1080P. Full HD video quality.
- Receive fast push notification from the zone and motion detection function.
- Two way audio.








Packaging Details


Once packeg has been opened, you will find the below items:

- 1. O1 Wireless Security Camera *1
- 2. 5v Power adapter *1
- 3. Screw package *1
- 4. Quick installation guide *1






5V Power Adapter x 1



Accessories Package x 1



Quick Installation Guide x 1





A. Appearance Description

Switch Switch on the camera.

Reset Press the reset button for 5 seconds, until you hear "Factory Default Settings"

SD Card Supports micro SD card local storage (mac support 128G). After inserting SD card login to the Interfree Application

to format it

Power Adapter 5V-1A.

Battery 18650

Speaker Supports two way audio and voice prompt.









B: The Interfree Application Download


Please use your phone to scan the QR code or search "Interfree" APP in APP store or Google play.







Download Now









Wifi Configuration


1. Enter the App, click "+" to add new device.



Click on the "+" icon to add your first device to the network



By clicking on "+Add", You can add as many devices to interfree's network




Scan the QR code on device

Note: When using the device for the first time, the device will appear offline. You will need to setup the device without scanning. This device can only connect to 2.4G Wi-Fi.






2: When using the device for the first time, the device will appear offline on the app. Turn the device on and connect to a Wi-Fi network. Ensure the Wi-Fi network in 2.4G.








3: Click the push button, then press the reset button untill you hear 'Reset To Factory Setting' the device will then need approximately 20 seconds to enter AP mode. After 20 seconds you will hear Waiting for Configuration, then press 'Next'







4: Connect the device to the Wi-Fi network and enter the Wifi Password. Click 'Next' the device will then being configuration the information.













5: Keep your phone close to the device during configuration. Once the device configured, the user will be notified.








6: Once User here 'The connection is successful' the configuration is complete. Then add the de and create the device name and password.







Step 8: Access the device from your mobile phone.



View status of the device, such as battery life and WIFI

View the


History.

device's log





Step 9: Access the device from your mobile phone.









INSTALLATION

Install the bracket (optional)

Screw fixes onto the wall and place the bracket onto the screw cap.

2. Install the camera

Place the camera onto the fixed bracket, as shown in the figure below.

3. Installation finished

Freely and easily adjust the camera viewing angle.









O₁ Wireless
SECURITY CAMERA

- 33 Glenvale Crescent Mulgrave VIC 3170 Australia
- interfree@interfree.com.au
- www.interfree.com.au