



iBUZZ

SMART DOOR BELL



1080P
Full HD



Weather
Resistant



Two-Way
Audio



Notification
Push to
Mobile Device



2.4G
Wifi



PIR Motion
Detection



Night
Vision



166° Wide-angle
Camera Lens



Long
Battery Life

Product Features

- Support 2pcs 18650 battery and sustainable standby for 6 months.
- Built in IR still visible at night.
- 110-degree field of view with 1080P. Full HD video quality.
- Receive real time notifications when motion is detected.
- Two-way audio.
- Visit Alert.



Packaging Details

Once package has been opened, you will find the below items.

- IBuzz doorbell x 1
- Chime x 1
- 18650 batteries x 2
- Screws pack
- User Manual x 1
- Mini USB charging cable x 1

Appearance Description


Reset Press the reset button for 5 seconds, until you will hear the sound “Factory Default Settings”

SD Card Support micro SD card local storage (Max support 128G), after inserting SD card please login Interfree application to format it).


Power Adapter 5V-1A.

Battery 18650

Speaker Supports two way audio and voice prompt.




Appearance Description






Step 1: Interfree Application Download

Please use your phone to scan the QR code or search "Interfree" APP in APP store or Google play.




Download Now




Step 2 : Wifi Configuration


Enter the APP, click “+” to add new device.



Clicking on the “+” icon to
to add your first device
to the network




By clicking on “+add”
you can add as many
devices to interfree’s network




Click on Setup
without scanning

Note: When using the device for the first time, device will be offline. You will need to setup the device without scanning. This device can only connect 2.4G wifi (add to all cameras)


2: When using the device for the first time, the device will appear offline on the app. Turn the device on and connect to a wifi network. Ensure the wifi network is in 2.4G.



Step 4: Click the push button, then press the reset button until you hear 'Reset To Factory Setting' the device will then need approximately 20 seconds to enter AP mode. After 20 seconds you will hear 'Waiting for Configuration', then press 'Next'







Step 5: Connect the device to the Wi-Fi network and enter the Wifi Password. Click 'Next' the device will then being configuration the information.



9:41 📶 🔋

← **Add Device**

Please enter the WiFi password that you want to configure for the device, then click Next

Select Wifi

Please Choose a Wi-Fi ▼

This device does not support 5G network temporarily


Password

Please enter the WiFi password


Save the Password

Next

Step 6: Once the device is configured, user will be notified.



Step 7: Once User has received 'The connection is successful' notification, add the device.
Then create the device name and password.



9:41

← Add Device

Create a name for the device and enter the device login password to complete the addition!

Device Name

Entrance

Account

Enter Account

Password


Enter the device login password

My Room


Select Room

Next

Step 8: Access the device from your mobile phone.



Step 9: Access the device from your mobile phone.



Installation

1. Install the bracket (optional)

Screw fixes onto the wall and place the bracket on the screw cap.


2. Install the camera

Place camera onto the fixed bracket, as shown in figure below.


3. Installation Finished

Adjust the camera viewing angle freely.

• Installation -Bracket Install




• Installation -Doorbell Install




Installation

• Power Supply Solution

Hard Wire Power Source



Powered by Battery






DOORBELL

R E C E I V E R C H I M E



IP55
Waterproof



300M
Wireless Range



38
Chord Ringtones



0-100dB
5 Level Volume

Specifications

Colour	White, Black optional
Dimension	8.2x8.2x5.25cm
Working Voltage	110-260V/50-60Hz
Working Temperature	-30°C~70°C
Working frequency	433.92MHz±280KHz
Ultra low power consumption	YES
Number of ringtones	38 optional
Working Distance	120-150M(Open area)
Volume	0-110dB, 5 levels adjustable
Certificates	CE,RoHS,FCC,PSE,TELCE

1. Plug the receiver into a mains socket and switch the socket on.

2. Press the IBuzz(doorbell) push button and confirm that the transmitter indicator flashing, the doorbell receiver sounds "Ding-Ding" and the receiver indicator flashes. Once the doorbell receiver sounds 'Ding-Ding' the doorbell has been paired. Please note that the default sound is 'Ding-Dong'. Refer to below steps to change doorbell sound.

CHANGING THE DOORBELL SOUND:


Step 1: Press the Backward or Forward button on the receiver to choose your favorite melody.

Step 2: Press and hold down the Volume button on the receiver for 5 seconds, until it makes a "Ding" sound and the receiver indicator flashes (after this the doorbell will be in pairing mode for 8 second, it will automatically exist pairing mode).

Step 3: Press the button on the doorbell quickly, it will makes a "Ding-Ding" sound and the receiver indicator with flashes.

Step 4: Press the button on the doorbell again to confirm whether the current sound is the one you have set, if sound is correct, the pairing is completed.


Remark: This method is also suitable for adding/pairing additional



Step 1



Step 2



Step 3 - 4

CLEARING THE SETTINGS :

Press and hold down the Forward button on the receiver for 5 seconds, until it makes a “Ding” sound and the receiver indicator flashes, After this all settings will be cleared and the chime will return to the factory default settings (the sound you have set with the iBuzz (doorbell) will be cleared.)

INSTALLATION:

1. Plug the Chime into a mains socket and switch the socket on.
2. Place the iBuzz(doorbell) where you intend to fix it, close the doors and confirm that the chime still sounds when you press the transmitter push button. If the chime doesn't sound, it may be out range and will need to be moved closer to iBuzz (doorbell)
3. Fix the iBUZZ doorbell in place with bracket.



ADJUSTMENT:

1. The volume of the Chime may be adjusted to one of five levels.

Press the Volume button on the chime to increase the volume by one level, the chime will sound to indicate the selected level. If the maximum level is already set, the doorbell will switch to the minimum level, which is the Silent Mode

2. The melody played by the doorbell may be set to any one of 35 different selections. Press the Backward or Forward button to select the next available melody, the receiver will sound to indicate the selected melody. To set the doorbell ringtone to the selected melody, please refer to the “CHANGING DOORBELL SOUND” steps

PROBLEMS?

If the Chime does not sound, the following are possible causes:

1. The battery of the IBUZZ doorbell may be run down (the IBUZZ doorbell indicator will not flash) Recharge the battery.
2. The battery may be inserted the wrong way (polarity reversed). Insert the battery correctly, but be aware that reverse polarity may damage the unit.
3. Ensure that the doorbell receiver is switched on at the mains.
4. Ensure that neither the IBUZZ doorbell or the receiver are close to possible sources of electrical interference, such as a power adaptor, or other wireless devices.
5. Range will be reduced by blockages such as walls or door. Ensure that avoidable objects (especially metal objects) have been placed between the transmitter and the receiver. If this is the case, the iBuzz Doorbell needs to be repositioned.

CAUTIONS:

1. Check that your mains supply is correct for the doorbell receiver.
2. The receiver is for indoor use only. Do not use outside or allow to become wet.
3. There are no user-serviceable parts. Do not attempt to repair either the transmitter or the receiver by yourself.

The benefits provided by this warranty are in addition to other rights and remedies available to a consumer under Australian consumer laws

1. Who is giving this warranty: Interfree Pty Ltd (ABN 64 632 361 383) (we, us or our) gives this warranty. Our contact details are:

Address: 33 Glenvale Crescent, Mulgrave, Victoria, 3170 Australia

Tel: +61 3 9239 2000

E-mail: warranty@interfree.com.au

2. What we will do at our cost: If your Interfree product, or any component of it, malfunctions during the warranty period (see below) due to defective components or workmanship, subject to the terms and conditions set out below, we will, at our option, at our cost, either:

- repair the defective product or component; or
- replace the defective product or component with the same or comparable product or component.

If we decide to repair the defective product or component, we will be responsible for the costs of repairs, spare parts and labour. Any defective product or component we decide to replace, and any defective component removed in the course of repairs, will become our property.

We will also pay for the costs of transporting the repaired or replacement product to you, using a means of transport/carrier of our choice.

There are some costs you may have to pay if you make a claim under this warranty: refer to section 6 below.

3. Warranty period: The warranty period is one year from the date you purchase your product. Please keep your original invoice or sales docket for the product as proof of purchase. If we carry out any warranty work on your product or any component of it during the warranty period, that will not extend or renew the warranty period for the product, or for any replacement product or components that we provide as part of the warranty work.

4. This warranty is not transferable: Only the original purchaser of our product (when purchased new from us, from a retailer or from an installer of the product) may rely on this warranty. It is not transferable to subsequent purchasers of the product.

5. What you need to do to claim under this warranty: If you believe you have a claim under this warranty, please contact us by telephone or email using the contact details set out in section 1 above. If you email us, or leave a telephone message for us, please ensure you leave your name and your email address and/or a daytime telephone number so that we can contact you. Once we have made an initial assessment of your claim, we will let you know what action we will take. We may ask you to send us your original invoice or sales docket for the product as proof of your entitlement to make a claim.

6. Costs you may have to pay: If you make a valid claim under this warranty, you will have to pay the costs of:

- removing (uninstalling) the product. If, by law, your product can only be removed or uninstalled by a qualified and licensed electrician or similar tradesperson, you will need to engage such a person to do so, at your cost;
- transporting or shipping the repaired or replacement product from your premises to us (at our address, as set out in section 1 above). We recommend that, where possible, you use the original packaging a product came in when returning it so as to minimise the risk of damage in transit; and
- re(-)installing the repaired or replacement product. If, by law, the repaired or replacement product can only be (re-)installed by a qualified and licensed electrician or similar tradesperson, you will need to engage such a person to do so, at your cost.

If, on inspecting your product, we determined that the product was not defective, or that any defect in your product was not covered by this warranty, we would let you know. In that case:

- you will have to pay the costs of transporting or shipping the product back to you, if you wanted the product returned. If you tell us you do not want the product returned, do not agree to pay return transport/shipping costs or you do not make arrangements to collect the product from us within 12 months after we notify you, the product will become our property (without our being required to pay you), and we may dispose of it at our discretion; and
- if you still wanted us to repair your product, you would also be responsible for the costs of the repair, including any applicable spare parts and labour.

We would let you know what the above costs were and seek your authorisation to charge you, before sending the product back to you or effecting any out of warranty repairs.

This does not limit your rights under the Australian Consumer Law.

7. What is not covered by this warranty: This warranty does not cover or apply to any of the following:

- Any consequential or indirect loss, costs or damages or loss of data which you suffer or incur.
- The costs described in section 6 above.
- Deliberate or negligent damage, or damage caused by failing to follow operating instructions.
- Products which have been stored incorrectly, used inappropriately, abused or misused.
- Products which are not specified by us as being suitable for outdoor use having been placed, installed or used outdoors.
- Damage caused by connection to the wrong voltage, power outages, electrical power surges or improper supply voltage.
- Any damaged caused by water or immersion of a product in water (except to the extent that the product has been used in a wet environment in accordance with our instructions).
- The failure of any “smart” product to operate, to the extent the failure is caused by the unavailability or inadequacy of, or interruption to, any internet, wi fi or power supply, service or connection which we specify is necessary for the proper operation of the product.
- Damage caused by acts of God (including but not limited to lightning, flood, cyclone, earthquake or unusually severe weather).
- The depletion or replacement of any consumable parts of our products (such as batteries).
- Damage caused by vermin or insects.
- Damage caused during the transportation of products (except where we arranged transport).
- Cases where no fault or defect in the product or its components could be found by us (in which case, please refer to paragraph 8 below).
- Products which have been installed by non-qualified persons (please note that by law, some of our products can only be installed by a qualified and licensed electrician or similar person).
- Products or their components which have been repaired or modified by anyone not authorised by us in writing.

8. Your additional legal rights if you are a consumer: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



iBuzz
SMART DOOR BELL

 33 Glenvale Crescent Mulgrave VIC 3170 Australia

 interfree@interfree.com.au

 www.interfree.com.au